

MEYLE

DRIVER'S BEST FRIEND

MEYLE

Assembly instruction for shock absorbers

Einbauhinweis für Stoßdämpfer
Instrucciones de montaje para amortiguadores
Instructions de montage pour amortisseurs
Инструкция по установке амортизаторов
Istruzioni di montaggio per ammortizzatori



MEYLE no. 226 615 0002

Short no. MSA0170

To fit/Passend für/Aptos para/Convient pour/для/Adatti per

Fiat

MEYLE



**Installation by qualified personnel only.
Car manufacturer's instructions to be
observed closely.**

Einbau nur durch geschulte Fachkräfte. Hinweise der Fahrzeughersteller genau befolgen.

El montaje sólo debe realizarse por un técnico instruido. Siga exactamente las indicaciones del fabricante del vehículo.

Installation uniquement par main-d'oeuvre spécialisée. Suivre les indications du fabricant d'automobile pour l'installation.

Монтаж должны производить только обученные специалисты.

Следует точно соблюдать инструкции завода-изготовителя автомобиля.

Montaggio solo da parte di meccanici specializzati. Sono da seguire esattamente le istruzioni fornite dal costruttore del veicolo.

MEYLE AG

Merkurring 111, 22143 Hamburg, Germany, www.meyle.com

W02.2010

