



Surely you have experienced or seen it yourself...a bitten insulation mat or one with slack?

Many car drivers see the solution in simply removing the mat and not installing a new one. But this is suboptimal and not very vehicle-friendly

**Here are three good reasons to equip your vehicle with an insulation mat:**



1. It protects the bonnet from overheating
2. It reduces the noise level
3. It slows down the cooling down of the engine > useful in winter

**Insulating mat for Mercedes Benz**

AIC- Article No.: 57095

OE- Ref. No.: 156 682 0100



**Insulating mat for VAG**

AIC- Article No.: 57118

OE- Ref. No.: 1C0 863 835K



Since last year, AIC has been offering 40 different insulating mats in its range, including fastening rivets, which are specially made to fit the bonnet of your car.

Just have a look at our offer overview on the next page.

# Offer overview - Insulating mats from



AIC- Article No.	OE- Ref. No.	Manufacturer
57095	156 682 0100	Mercedes Benz
56014	5K0 863 831G	VW / Audi
56083	1K0 863 831D	
57100	8E0 863 825AF	
57101	8E0 863 825AJ	
57102	8T0 863 825H	
57103	4B0 863 825AG	
57104	4F0 863 825C	
57105	4G0 863 825	
57106	1T0 863 831B	
57107	1T0 863 831G	
57108	5N0 863 831B	
57109	5C6 863 831G	
57110	1Z0 863 831A	
57111	5J0 863 831	
57112	3T0 863 831	
57113	5JA 863 831	
57114	3B0 863 835H	
57115	5G0 863 831	
57116	3C0 863 831B	
57117	7P6 863 831A	
57118	1C0 863 835K	
57119	6Q0 863 835C	
57120	6R0 863 831B	
57121	1K8 863 831E	
57122	5C5 863 835	
57123	3G0 863 831A	
57087	5148 9 141 036	
57088	5148 7 059 260	
57089	5148 7 148 208	
57090	5148 6 989 301	
57091	5148 6 989 300	
57092	5148 7 326 999	
57093	5148 9 175 051	
57094	5148 7 158 420	
57436	5148 7 221 993	Ford
57096	1 136 361	
57097	1 519 736	
57098	1 562 666	
57099	1 145 263	
57124	958 556 831 00	Porsche